



## **CITRAJET®**

**Low-Foaming Liquid Acid Cleaner**

# Sample Trace Analysis Undiluted Concentrate

<b>ELEMENT</b>	<b>DETECTED</b>	<b>DETECTION LIMIT</b>
<b>Chlorine</b>	NONE	Less than 10.0 PPM
<b>Fluorine</b>	NONE	Less than 10.0 PPM
<b>Bromine</b>	NONE	Less than 10.0 PPM
<b>Iodine</b>	NONE	Less than 10.0 PPM
<b>Sulfur</b>	NONE	Less than 30.0 PPM
<b>Chromium</b>	NONE	Less than 1.0 PPM
<b>Lead</b>	NONE	Less than 0.1 PPM
<b>Antimony</b>	NONE	Less than 2.0 PPM
<b>Copper</b>	NONE	Less than 0.5 PPM
<b>Zinc</b>	NONE	Less than 10.0 PPM
<b>Bismuth</b>	NONE	Less than 0.01 PPM
<b>Tin</b>	NONE	Less than 15.0 PPM
<b>Cadmium</b>	NONE	Less than 0.5 PPM
<b>Aluminum</b>	NONE	Less than 3.0 PPM
<b>Sodium</b>	NONE	Less than 20.0 PPM
<b>Silicates</b>	NONE	Less than 10 PPM

Recommended dilution is 2% (2.5 Oz. CITRAJET per gallon of water). When diluted, the amount of the above chemical traces will of course be diluted.